

## SEI Cellular Calling Features

- Using 3-Way Calling
- Setting up Voice Mail
- Using Call Waiting
- Using Call Forwarding
- Using Caller ID
- Using Caller ID Blocking

### **Using 3-Way Calling**

---

While on the first call, dial the 10-digit number of the second person.

Press SEND ; the first person is automatically put on hold while the call is made.

When the second person answers, press SEND to create a conference call.

If the second person does not answer, press the SEND key twice to end the connection and go back to the first person.

To end both conversations, press the END key.

### **Setting up Voice Mail**

---

Dial \*VM (\*86).

Press SEND.

When you hear the system greeting, press # (pound button) immediately to interrupt the greeting.

Follow the set-up tutorial which will walk you through selecting a password, recording your personal greeting and more.

### **Setting up Call Waiting**

---

When you are on a call and a second call comes in, you will hear a tone to let you know that you have another call. When that happens, you have two choices:

Put the first call on hold by pressing SEND. You will automatically be connect with the second call. To return to the first call, press SEND again. To switch between the two calls, press SEND.

-OR-

End the first call by asking the first caller to hang up. This automatically connects you to the waiting caller

To cancel Call Waiting: Before a call, dial \*70 + the 10-digit number you are calling and then press SEND.

### **Setting up Call Forwarding**

---

To activate Call Forwarding:

Press \*72.

Enter the phone number where you want the calls to be forwarded.

Press SEND. You will hear a confirmation tone or message.

Press END.  
To deactivate Call Forwarding:  
Press \*73.  
Press SEND. You will hear a confirmation tone or message.  
Press END.

## **Caller ID**

---

In order for Caller ID to work, the called party must:  
Have a Caller ID-capable phone.  
Have the Caller ID feature activated.  
Be traveling in an area that supports Caller ID.

## **Setting up Caller ID Blocking**

---

To activate Caller ID Blocking when placing a call:  
Press \*67.  
Dial the number.  
Press SEND. The words "Private", "Anonymous", or some other text will appear on the called party's caller ID device instead of your wireless phone number.  
To activate Caller ID Blocking on all calls to a specific number:  
Dial \*82.  
Dial the number.  
Press SEND.